

1.0 GENERAL**1.1 Summary**

Contractor shall furnish, install and finish a vinyl wallcovering as specified in the contract documents.

1.2 Sample

Contractor shall submit for the architect's approval – a sample of each texture, type or color to be installed.

1.3 Compliance

Submit certification that the manufacturer's wallcovering meets the architect's specifications. Submit documentation that the manufacturer's wallcovering meets NSF/ANSI 342 for sustainability, California Indoor Air Quality CA-1350 as well as Federal certifications CCC-408-D for wallcovering products.

1.4 Warranty

Contractor will supply the manufacturer's written warranty against defects in workmanship for 5 years from date of installation. Submit manufacturers written warranty.

1.5 Delivery, Storage and Handling

All necessary materials for installation including wallcovering, primer and adhesives must be delivered to the job site undamaged. All containers are to be clearly marked with the manufacturers identification label. Store vinyl wallcovering rolls horizontally and materials in a clean, dry area where temperature and humidity remain constant and within the manufacturers specifications.

1.6 Project Conditions

Environmental conditions must remain constant and over 65 degrees Fahrenheit for at least four days before and throughout the installation and 4-7 days thereafter. Walls shall be finished to the Architect's specification and be free of surface defects and dirt. The Contractor for the installation process must provide sufficient lighting and access.

2.0 PRODUCTS

2.1 Vinyl Wallcoverings

All vinyl wallcoverings specified and installed shall meet the latest GSA Federal Specification

*CCC-W-408-D. In addition, wallcoverings must meet or exceed Wallcovering Association Quality Standard

*W-101-2017 for Vinyl Coated Fabric Wallcovering. All Type I (15 oz) and Type II (20 oz) wallcoverings specified shall pass the ASTM-G21 testing for mold and mildew resistance.

*The ASTM-E84 test must be passed with the wallcovering mounted to common gypsum wallboard.

2.2 Flame and Smoke Characteristics

The manufacturer shall certify that the vinyl wallcovering supplied meets Federal and International specified limits for flame, smoke development and flash over according to the following tests:

ASTM E-84 Tunnel Test NFPA Life Safety Code 101

EU Class Flame (EN 15102)

CAN/ULC S102

BS476 Part 7

Type II

Passed Class A Passed Class B, s2 Passed

Passed Class 1

Type I

Passed Class A Passed Class B, s2

2.3 Environmental

– All Versions Meets or exceeds EN12149 A,B,C – the EU Toxicity requirement for heavy metals (including Cadmium, Mercury, Lead and Antimony), and Formaldehyde under EN15102.

Manufactured without the use of Brominated Flame retardants.

Indoor Air Quality - Manufactured with Low VOC Vinyl

- Meets California CDPH Standard for Schools and Offices

- Tested per CA-1350

- WA Certified NSF/ANSI 342 Sustainability Standard

ARCHITECT'S SPECIFICATIONS for Decomurale DR2000 / NW1300 Wallpaper

Non-woven backing contains 11% post-consumer recycled content.

HPD

EPD

CONTRIBUTES TO LEED v4

Phthalate-free formulation Prop 65 compliant

2.4 Test Accreditation

All product testing for compliance with Federal Specifications shall be performed and evaluated by one or more of the following independent and accredited testing companies:

Intertek Testing Services NA, Inc.

Underwriters Laboratories Omega Point Laboratories, Inc.

2.5 Adhesives and Primers

Adhesives and Primers used must be of the type designed for vinyl wallcoverings.

Adhesives and Primers must contain mildew inhibitors (**Primer model Roman Pro 977**)

2.6 Ultra White Point

Unprinted white base film should measure no more than 0.5DE from the values below to ensure optimal printing conditions

Cielab values

L* 93.04 a* -0.27 b* -1.42 C* 1.45 ho 259.25

3.0 EXECUTION

3.1 Inspection

1. The Contractor shall provide a complete copy of Decomurale's current Hanging Instructions to the installer pertaining to the installation of the wallcovering. ALL INSTALLATIONS MUST CONFORM TO DECOMURALE'S CURRENT INSTALLATION INSTRUCTIONS AND PRODUCT TECHNICAL INFORMATION.

2. All labels shall be checked for accuracy by the installer to insure that the shipment is received as ordered.

3. If no defect is evident before installation, the material should be inspected after three (3) panels are installed. If any defect is evident at this time (or any point of the installation) no further material should be applied and Contractor should be contacted IMMEDIATELY.

3.2 Surface Preparation

- A. All hanging surfaces must be clean, smooth, dry, undamaged, free of mold, mildew, grease or stains, and structurally intact. All loose paint and other wallcoverings must be removed. If moisture is present, immediately identify and eliminate the source(s) of the moisture and verify that all wall surfaces are completely dry before proceeding.
- B. Any mold or mildew **MUST** be removed from walls and hanging surfaces prior to installation. Walls should not contain in excess of 4% residual moisture content. A moisture meter should be used to determine moisture content. Moisture infiltration and accumulation can lead to mold or mildew growth and must be corrected **PRIOR** to the installation of the wallcovering. This product is intended for use in buildings that are properly designed and maintained to avoid moisture infiltration, condensation and or accumulation at wall cavities and wall surfaces, particularly in warm, humid climates. Old walls shall also be treated with bleach, Lysol and/or other approved, mildew – inhibiting products in order to inhibit further mildew growth.
- C. Proper surface preparation is key to getting great results. To prepare the surface properly, we recommend that you prime all surfaces with a universal, white- pigmented, mold inhibiting wallcovering primer (**Roman Pro 977 or equivalent**).
- D. For new drywall construction, a coat of **Roman Pro model 977** or equivalent wallcovering primer shall be applied to the surface before application of wallcovering. Use a primer that dries to a solid color to conceal drywall joints.
- E. Use only a lead pencil for marking walls and back of wallcovering. Do not use ballpoint or marking pen, they will bleed through the surface.

ARCHITECT'S SPECIFICATIONS for Decomurale DR2000 Vinyl Wallcoverings

F. Do not install wallcovering unless a temperature above 65o degrees F is maintained in both areas of installation and storage for at least 48 hours prior to installation.

3.3 Installation

1. If the application is a textured or non-matched wallcovering pattern, reverse hanging of alternate panels is required to ensure color continuity from strip to strip. If the application is a mural it is recommended that every other panel is rotated 180 degrees when printing to minimize the side-to-side color shift that may occur with each printer.
2. Determine whether the pattern match is random, straight across, or drop match. Measure the wall height, allowing for pattern match, add 4 inches, and then cut the wallcovering. It will overlap onto the ceiling and the base approximately 2 inches. Apply the recommended adhesive to the back using either a pasting machine or a paint roller. Work the adhesive in, to cover the back completely, especially near the edges. Fold each end toward the middle, pasted sides together, aligning the edges carefully so they do not dry out. CAUTION: Do not crease wallcovering. Allow to "relax" for ten minutes (booking). This will allow the adhesive to penetrate the wallcovering fabric, which is important to a successful installation.
3. WITH ALL DIRECTIONAL PATTERNS, IT IS IMPORTANT TO LINE UP PATTERNS AT EYE LEVEL ALLOWING ANY DRIFT IN LINEUP TO RUN OFF TOWARD CEILING AND FLOOR. THE STANDARD ALLOWANCE IS ONE QUARTER OF AN INCH UP OR DOWN. IF PATTERN IS LINED UP AT THE CEILING THE PATTERN WILL BEGIN MISALIGNMENT SOONER AND THE GAP WILL BE LARGER. ALSO, MOST PATTERNS WILL BE VIEWED AT EYE LEVEL THEREFORE IT IS THAT AREA THAT NEEDS TO LOOK ALIGNED. IF THERE ARE ANY QUESTIONS ABOUT PATTERN LINEUP, CONTACT SUPPLIER. BE SURE FIRST DROP OF WALLCOVERING IS SQUARE ON WALL BY PLUMBING THE WALL AND USING A LEVEL.
4. Avoid burnishing the face of the material. Use a wallcovering brush or a plastic scraper to smooth the wallcovering onto the wall. For optimal durability wererecommend the use of a liquid topcoat to protect the surface of the wallcovering pattern from stain and abrasion.

ARCHITECT'S SPECIFICATIONS for Decomurale DR2000 Vinyl Wallcoverings

5. Do not rub. Do not allow vinyl adhesive to dry on surface as it may leave a white residue. Wash off excess paste from face of wallcovering as you hang it with a cellulose sponge. The cellulose sponge must be rinsed in clean water after every use. Blot dry with a clean cloth.
6. Place the second strip to the edge of the first strip. Tape seams before overlapping and double cutting to avoid getting adhesive on the wallcovering. If paste does get on the vinyl, clean it off immediately with clean warm water and blot dry with a clean lint less towel. Use a soft bristle brush to wash the ceiling and the baseboard to remove any paste residue. Do not leave any overlap on the seams since vinyl will not adhere to itself. *Seams should be vertical, have a tight fit, and be free from air and paste bubbles. Seams should not be located closer than 6" to corners. After three panels are smoothed to wall surface and excess paste removed, examine the installed panels for color uniformity. Any objectionable variations in colormatch, pattern match, etc should be immediately communicated to the printer for inspection before proceeding further with installation.
7. After installation, the walls and wallcovering should be monitored for potential moisture or vapor infiltration or accumulation. Any such infiltration/accumulation after installation must be promptly eliminated in order to reduce the risk of mold/mildew growth.

3.4 Clean up and Completion

Upon completion of work, remove all surplus material and debris from work site. All work sites must be clean and orderly upon installation crew departure.